



# Air Pen

USE WITH GRS AIR SYSTEM • #004-524

**FIG.1**

Connect Air Pen hose to  
Aux Output port.  
*GraverMach AT shown  
here. Aux output is on the  
front of the GraverMax G8.*



**FIG.2**



## Machine Front

Turn Aux knob to start  
the airflow.

**NOTE: 70 PSI  
(4.8 Bar) Max.**

**FIG.3**



Press the button on the  
pen to blow air.

## Replacement part

050-002 Tubing .250" 6 ft (1.8 m)

# GLENDO LLC

900 Overlander Road • Emporia, KS 66801 USA  
800-835-3519 • 620-343-1084 • Fax: 620-343-9640  
grs@grstools.com • www.grstools.com  
Last Update: 04/11/2023



# Air Pen

USE WITH AIR COMPRESSOR • #004-524

**FIG.1**

Connect Air Pen hose to compressor output.  
*An adapter may be required for the .250" hose to fit.*



**FIG.2**



**FIG.3**



Press the button on the pen to blow air.

### **Replacement part**

050-002 Tubing .250" 6 ft (1.8 m)

# GLENDO LLC

900 Overlander Road • Emporia, KS 66801 USA  
800-835-3519 • 620-343-1084 • Fax: 620-343-9640  
grs@grstools.com • www.grstools.com  
Last Update: 04/11/2023